

# UNCLASSIFIED

AD NUMBER
AD830098
NEW LIMITATION CHANGE
TO Approved for public release, distribution unlimited
FROM Distribution authorized to U.S. Gov't. agencies and their contractors; Critical Technology; 15 SEP 1958. Other requests shall be referred to Space and Missile Systems Organization, Los Angeles, CA 90045.
AUTHORITY
SAMSO USAF ltr, 28 Feb 1972

THIS PAGE IS UNCLASSIFIED

AD830098

Classification Changed to:  
**UNCLASSIFIED**  
Authorized By: D D 254 MSCG  
Reclassified By: *Richard J. Cook*

~~CONFIDENTIAL~~

Date 5-14-65  
WS107A  
Date 12-1-65  
Rept.

RECEIVED

UNCLASSIFIED OCT 6 '58

ASTRONAUTICS  
TECHNICAL  
LIBRARY

PRELIMINARY OPERATING AND  
MAINTENANCE INSTRUCTIONS  
FOR  
GROUND HYDRAULIC SYSTEM  
(B & C SERIES)

RECEIVED

OCT 6 '58

ZE-7-137

ASTRONAUTICS  
TECHNICAL  
LIBRARY

15 September 1958

This document is subject  
to special export controls and  
each copy furnished to foreign  
governments or foreign  
national is made only  
with prior approval of:  
Hq.SAMSO, LA., Ca. 90045  
Attn: SMSD

ASTRO-ENGINEERING  
DISTRIBUTION CENTER

LOG A-246

COPY NO. 3

Published by Support Publications  
for the  
HYDRAULICS GROUP  
ENGINEERING DEPARTMENT

SECURITY NOTICE

This document contains information affecting the national defense  
of the United States within the meaning of the Espionage laws, Title 18,  
U. S. C., Sections 793 and 794. The transmission or the revelation of its  
contents in any manner to an unauthorized person is prohibited by law.

UNCLASSIFIED



CONVAIR-ASTRONAUTICS  
CONVAIR DIVISION OF GENERAL DYNAMICS CORPORATION  
SAN DIEGO, CALIFORNIA

~~CONFIDENTIAL~~

ZE-7-137

## LIST OF EFFECTIVE PAGES

Total number of pages in this publication is 20 ,  
consisting of the following:

Page(s)	Date of Issue
Title	Original
"A"	Original
i to ii	Original
1-1 to 1-10	Original
2-1 to 2-6	Original

PREPARED BY

W. R. Hughes  
W. R. Hughes

GROUP

HYDRAULICS/  
LAUNCH CONTROL

CHECKED BY

R. C. Scarborough  
R. C. Scarborough

APPROVED BY

W. A. Schmidt  
W. A. Schmidt

CHECKED BY

R. G. Stoklosa  
R. G. Stoklosa

APPROVED BY

C. Bierman, Jr.  
C. Bierman, Jr.

Additional copies of this publication  
may be obtained by written request  
to Engineering Distribution, Mail  
Zone 521-27, Convair-Astronautics.

THIS DOCUMENT CONTAINS INFORMATION AFFECTING THE NATIONAL DEFENSE OF THE UNITED STATES WITHIN THE MEANING OF THE ESPIONAGE LAWS, TITLE 18,  
U. S. C., SECTIONS 793 AND 794. THE TRANSMISSION OR THE REVELATION OF ITS CONTENTS IN ANY MANNER TO AN UNAUTHORIZED PERSON IS PROHIBITED BY LAW

A

~~CONFIDENTIAL~~

ISSUED 15 September 1958

~~CONFIDENTIAL~~

ZE-7-137

RECEIVED

OCT 6 '58

TABLE OF CONTENTS

ASTRONAUTICS  
TECHNICAL  
LIBRARY

Section	Page	Section	Page
I INTRODUCTION . . . . .	1-1	II OPERATION . . . . .	2-1
1-1 Introduction . . . . .	1-1	2-1 Operation of Hydraulic Control System . . . . .	2-1
1-3 Applicable Documents . . . . .	1-1	2-3 Control Panel Meters . . . . .	2-2
1-4 Scope . . . . .	1-1	2-4 Local Hydraulic Supply Trailer . . . . .	2-2
1-6 Description of System . . . . .	1-1	2-5 Blockhouse Control Panel . . . . .	2-2
1-8 Description of Major Components . . . . .	1-1	2-6 Indicating System . . . . .	2-2
1-9 General . . . . .	1-1	2-8 Calibration Panels . . . . .	2-3
1-10 Power Source . . . . .	1-2	2-9 Pressure Transducers . . . . .	2-3
1-11 Pneumatic System . . . . .	1-2	2-10 Temperature Transducers . . . . .	2-3
1-12 Local Control Panels . . . . .	1-2	2-11 Transducer Excitation Power . . . . .	2-3
1-13 Blockhouse Hydraulic Control Panel . . . . .	1-2	2-12 Calibrating Instructions . . . . .	2-3
1-14 References . . . . .	1-3		
1-15 Applicable Drawings . . . . .	1-3		
1-16 Equipment List . . . . .	1-4		

LIST OF ILLUSTRATIONS

Number	Title	Page	Number	Title	Page
1-1	Hydraulic Supply and Control System . . . . .	1-6	2-1	Typical Hydraulic Temperature and Pressure Indicating System . . . . .	2-5
1-2	Hydraulic Control . . . . .	1-7	2-2	Panel Calibrating Twin Temperature Recorder . . . . .	2-6
1-3	Helium System Control Panel . . . . .	1-8	2-3	Panel Calibrating Twin Pressure Recorder . . . . .	2-6
1-4	Hydraulic System Control Panel . . . . .	1-9			
1-5	Blockhouse Hydraulic Control Panel . . . . .	1-10			

THIS DOCUMENT CONTAINS INFORMATION AFFECTING THE NATIONAL DEFENSE OF THE UNITED STATES WITHIN THE MEANING OF THE ESPIONAGE LAWS, TITLE 18, U. S. C., SECTIONS 793 AND 794. THE TRANSMISSION OR THE REVELATION OF ITS CONTENTS IN ANY MANNER TO AN UNAUTHORIZED PERSON IS PROHIBITED BY LAW.

ISSUED 15 September 1958

~~CONFIDENTIAL~~

i

~~CONFIDENTIAL~~

ZE-7-137

LIST OF TABLES

Number	Title	Page	Number	Title	Page
1-1	Pressure Gage Switch		1-4	Booster Control Panel	
	Indications . . . . .	1-2		Functions . . . . .	1-4
1-2	Temperature Gage Switch		1-5	Equipment List . . . . .	1-5
	Indications . . . . .	1-3	2-1	Functions of Blockhouse	
1-3	Outlet Pressure Gage			Control Panel	
	Switch Indications . . . . .	1-3		Meters . . . . .	2-2

~~CONFIDENTIAL~~

ISSUED 15 September 1958

## SECTION I

### INTRODUCTION

#### 1-1. INTRODUCTION.

1-2. This manual provides preliminary operating and maintenance instructions for the blockhouse hydraulic control panel associated with the XSM-65 missile B & C series. In addition it covers associated equipment connecting the control panel with the ground and airborne hydraulic systems. The instructions are based on information available on the date of publication and are interim in nature. The manual will be revised as additional information is developed through actual operating and maintenance experience at the factory and test sites. Complete reissues of the manual will be made periodically. Personnel concerned with the operation and maintenance of the system can contribute to the effectiveness of the revised manuals by forwarding any comments to the Hydraulics Design Group, or to Support Publications, Convair-Astronautics.

#### 1-3. APPLICABLE DOCUMENTS.

- a. ZM-7-252B, Preliminary Operating and Maintenance Instructions for the Hydraulic-Pneumatic Supply Unit Trailer Mounted.
- b. ZE-7-111, Preliminary Operating and Maintenance Instructions for "B" Series Hydraulic Systems.
- c. ZE-7-124 P.O.M.I. for "C" Series Airborne Hydraulic Systems.

#### 1-4. SCOPE.

1-5. The blockhouse hydraulic control panel system provides a means of controlling and

monitoring the ground and airborne hydraulic systems for checkout exercises or actual launchings.

#### 1-6. DESCRIPTION OF SYSTEM.

1-7. The blockhouse hydraulic control system is composed of two primary sections described as follows:

- a. Blockhouse Hydraulic Control Panel is a remotely located panel for controlling and monitoring the ground and airborne hydraulic systems.

- b. Electrical Control System provides means for transmitting intelligence from the blockhouse hydraulic control panel to the hydraulic supply unit. In addition it provides means for transmitting information from ground and airborne hydraulic systems to the blockhouse hydraulic control panel.

- c. Instrumentation provides means of changing hydraulic pressures and temperatures into electrical impulses that can be transmitted to the blockhouse hydraulic control panel.

#### 1-8. DESCRIPTION OF MAJOR COMPONENTS.

1-9. GENERAL. The airborne hydraulic system is supplied, until launching, from two identical trailers. One trailer supplies the booster requirements while the other supplies the sustainer requirements. There are two sets of controls for the booster and sustainer supply systems. The controls in

## Section I

### Paragraphs 1-10 to 1-13

~~CONFIDENTIAL~~

ZE-7-137

each system operate in parallel, (see figure 1-1). The hydraulic supply system can be operated either from the local control panel or the remote control panel. When operated from the local panel the remote controls are deactivated and vice versa. However when remote indications are available on local or remote, the controls (remote and local) permit operation of the following:

- a. Ground pump motor start and stop.
- b. Bypass valve open and close.

1-10. POWER SOURCE. Commercial power (440-volt, 3-phase, 60-cycle) is furnished to the supply trailers from the pad facility control system. In case of commercial power failure, 3-phase, 440-volt, 60-cycle, 150-kw power is supplied from an emergency diesel generator to the tactical panel (TP18) through the automatic transfer switch.

Twenty-eight volts dc for both local and remote control is furnished from the 440-volt, ac line by a conversion unit, located in each supply trailer.

#### CAUTION

To prevent damage to the hydraulic pump make certain the phase rotation is as shown in figure 1-2.

1-11. PNEUMATIC SYSTEM. (See figure 1-3.) The pneumatic pressure medium, helium, is routed to one hydraulic-pneumatic supply trailer through the pressurization control unit. The pneumatic system supplies gas at pressures up to 2200 psig to the engine manifold. This pressurized gas is used for valve control and airborne hydraulic reservoir pressurization. Just prior to launch, the internal helium supply is obtained from one of the airborne helium storage bottles for valve control. During flight,

hydraulic reservoir pressurization is provided from the main fuel tank pressure sensing line.

1-12. LOCAL CONTROL PANELS. The local control panels as shown in figures 1-3 and 1-4 are located in hydraulic-pneumatic trailers 7-09241-1 or 7-09241-3. These panels are typical of both trailers and allow complete control of the hydraulic-pneumatic supply trailer.

1-13. BLOCKHOUSE HYDRAULIC CONTROL PANEL. (Also called the Remote Control Panel.) The blockhouse hydraulic control panel (see figure 1-5) contains the following controls and instrumentation:

- a. Missile inlet pressure gage. This is a high pressure gage (0 to 4000 psig) that is controlled by a three position selector switch as shown in table 1-1.

Table 1-1. Pressure Gage  
Switch Indications

SWITCH POSITION	INDICATION
Booster	Booster section inlet pressure from a transducer located in the launcher.
Sustainer	Sustainer section inlet pressure from a transducer located in the launcher.
Off	Gage not energized.

~~CONFIDENTIAL~~

NOTE

This gage although rated for 0 to 4000 psig will not register pressures greater than 3000 psig due to a gage saver installed in the pressure transducer.

b. Inlet Temperature Gage. This is a temperature gage (0° F - 200° F) with indication controlled by a five-position selector switch as shown in table 1-2.

Table 1-2. Temperature Gage  
Switch Indications

SWITCH POSITION	INDICATION
Missile	
Booster	Booster section inlet temperature from a transducer located in the launcher.
Sustainer	Sustainer section inlet temperature from a transducer located in the launcher.
Ground Pump	
Booster	Booster section inlet temperature from a transducer located in the booster hydraulic supply unit trailer.
Sustainer	Sustainer section inlet temperature from a transducer located in the sustainer hydraulic supply unit trailer.
Off	Gage not energized.

c. Missile Outlet Pressure Gage. This is a low pressure gage (0-150 psig) that is controlled by a three-position selector switch as shown in table 1-3.

Table 1-3. Outlet Pressure Gage  
Switch Indications

SWITCH POSITION	INDICATION
Booster	Booster outlet (return) pressure from a transducer located in the launcher.
Sustainer	Sustainer outlet (return) pressure from a transducer located in the launcher.
Off	Gage not energized.

NOTE

This gage although rated for 0 to 4000 psig will not register pressures greater than 3000 psig due to a gage saver installed in the pressure transducer.

d. Lights and switches for the booster hydraulic control panel function as shown in table 1-4.

e. Lights and switches for the sustainer hydraulic control panel function identically as shown in table 1-4.

1-14. REFERENCES.

1-15. APPLICABLE DRAWINGS.

a. 7-68126 - Console - Control Hydraulic.



Section I  
Paragraph 1-16

~~CONFIDENTIAL~~

ZE-7-137

Table 1-4. Booster Control Panel Functions

UNIT	DESCRIPTION
Panel Control	Green lamp is illuminated when hydraulic supply unit control switch is in the remote position.
Missile Pump Operating Light	Green lamp is illuminated when booster section missile pump is operating at a discharge pressure of 2300 $\pm$ 100 psig.
Ground Pump Operating Light	Green lamp is illuminated when hydraulic supply unit pump is operating.
Ground Pump Control Switches	Allow remote operation of the booster hydraulic supply unit pump.
Bypass Valve Lights	Amber lamp is illuminated when bypass valve is in "open" position. Green lamp is illuminated when bypass valve is in "closed" position.
Bypass Valve Control Switches	Allow remote operation of the booster hydraulic supply unit bypass valve.

b. 7-68631 - Diagram - Wiring, Console, Control, Hydraulic.

c. 7-68172 - Interconnecting Box - Hydraulic.

d. 7-65654 - Diagram - Schematic Hydraulic Control, Sycamore S-2.

e. 7-65695 - Diagram - Schematic Control Instrumentation.

1-16. EQUIPMENT LIST. A typical system is shown in table 1-5.

THIS DOCUMENT CONTAINS INFORMATION AFFECTING THE NATIONAL DEFENSE OF THE UNITED STATES WITHIN THE MEANING OF THE ESPIONAGE LAWS, TITLE 18, U.S.C., SECTIONS 793 AND 794. THE TRANSMISSION OR THE REVELATION OF ITS CONTENTS IN ANY MANNER TO AN UNAUTHORIZED PERSON IS PROHIBITED BY LAW.

~~CONFIDENTIAL~~

~~CONFIDENTIAL~~

Section I

ZF-7-137

Table 1-5. Equipment List

ITEM	DESCRIPTION	REFERENCE	AN NO.
Z-2	Console control hydraulic	7-68126	----
P201	Plug	92-40005-002	3106E-32-7S
P101	Plug - part of trailer	68-107632-13S	----
P102	Plug - part of trailer		
P203	Plug Temp. XDRC. R311	92-40002-002	3106E-12S-3S
P204	Plug Press. XDRC. R313	92-40003-016	3106E-14S-7S
P205	Plug Press. XDRC. R312	92-40003-016	3106E-14S-7S
P206	Plug Temp. XDRC. R314	92-40002-002	3106E-12S-3S
P207	Plug Press. XDRC. R316	92-40003-016	3106E-14S-7S
P208	Plug Press. XDRC. R315	92-40003-016	3106E-14S-7S
TBH	Interconnecting Box Hydraulic	7-68172	----
----	Hydraulic Supply Trailer	7-09241-1 or -3	----
R311	Transducer (0-200) °F. Booster	89-05001-005	----
R312	Transducer (0-4000) psi Booster	7-06373-801	----
R313	Transducer (0-150) psi Booster	7-06373-5	----
R314	Transducer (0-200) °F. (Sustainer)	89-05001-005	----
R315	Transducer (0-4000) psi (Sustainer)	7-06373-801	----
R316	Transducer (0-150) psi (Sustainer)	7-06373-5	----
PS 1	Power Supply 28 Volts VDC	96-97012-001	----
Z150	Panel Calibrating Recording Meter	7-68231-819	----
Z151	Panel Calibrating Recording Meter	7-68231-821	----
Z154	Panel Calibrating Recording Meter	7-68231-827	----
Z155	Panel Calibrating Recording Meter	7-68231-829	----
R201	Resistor 422 $\Omega$ 1/8w	97-47062-001	----
R202	Resistor 422 $\Omega$ 1/8w	97-47062-001	----
R203	Resistor 422 $\Omega$ 1/8w	97-47062-001	----
M201	Missile Outlet Pressure	7-06294-803	----
M202	Inlet Temperature	7-06294-807	----
M203	Missile Inlet Pressure	7-06294-805	----

THIS DOCUMENT CONTAINS INFORMATION AFFECTING THE NATIONAL DEFENSE OF THE UNITED STATES WITHIN THE MEANING OF THE ESPIONAGE LAWS, TITLE 18, U.S.C., SECTIONS 793 AND 794. THE TRANSMISSION OR THE REVELATION OF ITS CONTENTS IN ANY MANNER TO AN UNAUTHORIZED PERSON IS PROHIBITED BY LAW.

ISSUED 15 September 1958

~~CONFIDENTIAL~~

1-5

ZE-7-137





Figure 1-1. Hydraulic Supply and Control System

# 22 CONSOLE-CONTROL HYDRAULIC



7C 55-0-2(C)

A.

### Figure

**B.**

~~CONFIDENTIAL~~

ZE-7-137

Section I




Figure 1-2. Hydraulic Control

ISSUED 15 September 1958

~~CONFIDENTIAL~~

1-7

~~CONFIDENTIAL~~

ZE-7-137




Figure 1-3. Helium System Control Panel

THIS DOCUMENT CONTAINS INFORMATION AFFECTING THE NATIONAL DEFENSE OF THE UNITED STATES WITHIN THE MEANING OF THE ESPIONAGE LAWS, TITLE 18, U.S.C. SECTIONS 793 AND 794. THE TRANSMISSION OR THE REVELATION OF ITS CONTENTS IN ANY MANNER TO AN UNAUTHORIZED PERSON IS PROHIBITED BY LAW.

~~CONFIDENTIAL~~

ISSUED 15 September 1958

~~CONFIDENTIAL~~

ZE-7-137

Section I




Figure 1-4. Hydraulic System Control Panel

THIS DOCUMENT CONTAINS INFORMATION AFFECTING THE NATIONAL DEFENSE OF THE UNITED STATES WITHIN THE MEANING OF THE ESPIONAGE LAWS, TITLE 18, U.S.C., SECTIONS 793 AND 794. THE TRANSMISSION OR THE REVELATION OF ITS CONTENTS IN ANY MANNER TO AN UNAUTHORIZED PERSON IS PROHIBITED BY LAW.

ISSUED 15 September 1958

~~CONFIDENTIAL~~


1-9



~~CONFIDENTIAL~~

ZE-7-137

HYDRAULIC



7C28-0-6 A

Figure 1-5. Blockhouse Hydraulic Control Panel

THIS DOCUMENT CONTAINS INFORMATION AFFECTING THE NATIONAL DEFENSE OF THE UNITED STATES WITHIN THE MEANING OF THE ESPIONAGE LAWS, TITLE 18, U.S.C., SECTIONS 793 AND 794. THE TRANSMISSION OR THE REVELATION OF ITS CONTENTS IN ANY MANNER TO AN UNAUTHORIZED PERSON IS PROHIBITED BY LAW.

~~CONFIDENTIAL~~

ISSUED 15 September 1958

## SECTION II

### OPERATION

#### 2-1. OPERATION OF HYDRAULIC CONTROL SYSTEM.

2-2. The following procedure is typical of either booster or sustainer control systems:

a. Local Procedure

1. Place S108 "local-remote" switch in "local" position.
2. Close hydraulic supply switch on pad facility console.
3. Close circuit breaker in hydraulic supply trailer.
4. Close S109 power switch on hydraulic supply trailer.
  - (a) Results of closing S109 power switch:
    - (1) Panel lights I106, I107, and I108 (W) on the trailer control panel come on.
    - (2) Bypass valve open lights I104 amber local and I208 amber remote come on.
    - (3) Remote control is inoperative.
5. Push S106 ground pump start button on the hydraulic supply trailer control panel.
  - (a) Result of depressed start button:
    - (1) Pump motor operating lights I101 (green) local and I207 (green) remote are energized.
6. After allowing three seconds for the pump motor to reach full speed, push S103, bypass valve close switch, on the hydraulic supply trailer control panel.
  - (a) Result of closed bypass valve switch:
    - (1) Bypass valve open lights I104 (amber) local and I208 (amber) remote come on.
    - (2) Bypass valve close lights I103 (green) local and I209 (green) remote come on.

7. After the booster hydraulic pump is operating, a pressure switch closes which transmits a ready signal. A similar action occurs in the sustainer system. The two pressure switches are interlocked and send the ready signal to the function safe panel located on the test conductors console.

b. Remote Procedure.

1. Place switch S108 (remote-local) on the hydraulic supply trailer control panel to remote. The results are as follows:

- (a) Assume the pump motor is stopped and the bypass valve opened.
- (b) The lights are in the condition as described in paragraph 2-2, a, 4, (a).
- (c) The panel control light I206 (green) is energized.

2. Push S207 ground pump start switch on the blockhouse control panel. The result is as follows:

- (a) Ground pump operating lights I207 (green) on the blockhouse control panel and I101 (green) on the trailer control panel illuminate.

3. After three seconds, the pump motor will attain speed, then push S211 close bypass valve switch on the blockhouse control panel. The results are as follows:

- (a) Bypass valve close lights I209 (green) and I103 (green) on the blockhouse control panel and on the hydraulic supply trailer control panel come on.
- (b) Bypass valve open lights I208 (amber) on the blockhouse control panel and I104 (amber) on the hydraulic supply trailer control panel go out.

## Section II

Paragraphs 2-3 to 2-7

~~CONFIDENTIAL~~

ZE-7-137

4. After the missile hydraulic pumps build up pressure to operational value, two pressure switches close, the results are as follows:

(a) A signal is generated to the test conductors console (function safe panel) indicating internal hydraulic safe.

(b) Missile pump operating lights I210 (green) and I205 (green) on the blockhouse control panel come on.

5. At missile flyaway, the umbilical eject two inch rise off signal shuts down the hydraulic trailers. The results are as follows:

(a) Ground pump operating lights (I207 and I101) (both green) on the blockhouse and supply trailer panels go out.

(b) Bypass valve close lights (I209 and I103) (both green) on the blockhouse and supply trailers go out.

(c) Bypass valve open lights (I208 and I104) (both amber) on the blockhouse and supply trailer panels come on.

6. At static firing sites, the ground hydraulic supply of 2000 psig standby, is maintained throughout the test.

### NOTE

When emergency switch S107, on the supply trailer panel, is depressed, the hydraulic trailer shuts down and the light indications are same as in paragraph 2-2, b, 5.

### 2-3. CONTROL PANEL METERS.

### 2-4. LOCAL - HYDRAULIC SUPPLY TRAILER.

### 2-5. BLOCKHOUSE CONTROL PANEL. (See table 2-1.)

### 2-6. INDICATING SYSTEM.

2-7. Each indicating system (see figure 2-1) consists of a transducer, calibration panel, and a 100-microamp dc meter. This meter is shunted to give a full scale deflection of one milliamp (dc). Provisions for connecting a one milliamp Esterline Angus Recorder are available on the calibration panel.

Table 2-1. Functions of Blockhouse Control Panel Meters

UNIT	FUNCTION(S)	RANGE
M201 Missile Outlet Pressure	Booster and Sustainer	(0-150 psi)
M202 Inlet Temp	Missile-Booster & Sustainer, Ground Pump-Booster & Sustainer	(0 - 200 F)
M203 Missile Inlet Pressure	Booster & Sustainer	(0-4000 psi)

THIS DOCUMENT CONTAINS INFORMATION AFFECTING THE NATIONAL DEFENSE OF THE UNITED STATES WITHIN THE MEANING OF THE ESPIONAGE LAWS, TITLE 18, U.S.C., SECTIONS 793 AND 794. THE TRANSMISSION OR THE REVELATION OF ITS CONTENTS IN ANY MANNER TO AN UNAUTHORIZED PERSON IS PROHIBITED BY LAW.

~~CONFIDENTIAL~~

ZE-7-137

Section II

Paragraphs 2-8 to 2-12

NOTE

If recorders are not connected, a 1500 ohm one watt resistor should be connected across the proper terminals of the calibration panel. (See figure 2-1.)

2-8. CALIBRATION PANELS. The calibration panels for the temperature and pressure indicating assemblies are situated in the rack beneath the control panels located in the blockhouse. A schematic of the Twin Temperature Recorder Panel is shown in figure 2-2. A schematic of the Twin Pressure Recorder is shown in figure 2-3.

2-9. PRESSURE TRANSDUCERS. The pressure transducers are of the potentiometer type, having a total element resistance of 1000 ohms. This value must be used for the transducers to be compatible with the calibration system.

2-10. TEMPERATURE TRANSDUCERS. The temperature transducers are the resistance probe type, wound with balco wire. They have a nominal resistance of 1815 ohms at 77 F.

2-11. TRANSDUCER EXCITATION POWER. Transducer excitation voltage (28 v, dc) is supplied from a regulated power supply located per site requirements.

2-12. CALIBRATING INSTRUCTIONS.

a. For pressure indicating system.

1. Mechanically set the panel meter to zero.
2. Connect a pressure source to the transducer. Source must have a pressure gage.
3. Set the full scale adjust (FS ADJ) to maximum resistance. Turn the CALIB

OFF RUN switch to RUN and apply 28 volts dc.

4. With zero pressure on the transducer, turn the ZERO ADJ set screw until the meter registers zero.

5. Increase the source pressure to the desired full scale reading. Do not exceed the pressure rating of the transducer.

6. Turn the full scale adjust (FS ADJ) set screw until the meter reads full scale.

7. Place the CALIB OFF RUN switch to CALIB.

8. Adjust the CALIB STD dial until the meter reads on the second major division below full scale.

9. Lock CALIB STD dial. The system now has an internal calibration checkpoint.

10. To calibrate, place the CALIB OFF RUN switch to CALIB.

11. Adjust the full scale adjust (FS ADJ) set screw so that the meter reads below full scale on the second major division.

NOTE

Do not move the CALIB STD dial from its set position unless it is necessary to change full scale pressure of the system.

12. Hold the CALIB RUN switch to RUN and the system is ready for operation.

b. For temperature indicating system.

1. Mechanically set panel meter to zero.
2. Connect a variable resistance (0-5000 ohms) to the system in place of the transducer.
3. Set the full scale adjust (FS ADJ) set screw to maximum resistance. Place the CALIB OFF RUN switch to RUN and apply 28 volts dc.
4. Set the variable resistance to a value equal to the probe resistance at 0° F. Setting is approximately 1500 ohms determined from the transducer calibration curve.

THIS DOCUMENT CONTAINS INFORMATION AFFECTING THE NATIONAL DEFENSE OF THE UNITED STATES WITHIN THE MEANING OF THE ESPIONAGE LAWS, TITLE 18, U.S.C., SECTIONS 793 AND 794. THE TRANSMISSION OR THE REVELATION OF ITS CONTENTS IN ANY MANNER TO AN UNAUTHORIZED PERSON IS PROHIBITED BY LAW

ISSUED 15 September 1958

~~CONFIDENTIAL~~

2-3

## Section II

~~CONFIDENTIAL~~

ZE-7-137

5. Turn the ZERO ADJ set screw until the meter reads zero.

6. Increase the variable resistance until it equals the resistance of the probe at 200 F. Setting is approximately 2400 ohms determined from the transducer calibration curve.

7. Turn the full scale adjust (FS ADJ) set screw until the meter reads full scale.

8. Place the CALIB OFF RUN switch to CALIB position.

9. Adjust the CALIB STD dial until the meter reads below full scale on the second major division.

10. Lock the CALIB STD dial. System now has an internal calibration check point.

11. To calibrate, place the CALIB OFF RUN switch to the CALIB position.

12. Adjust the full scale adjust (FS ADJ) set screw so the panel meter registers on the second major division below full scale.


### NOTE

Do not move the CALIB STD dial from its set position unless it is necessary to change the full scale reading of the system.

13. Place the CALIB RUN switch to RUN position and the system is ready for operation.

~~CONFIDENTIAL~~

ISSUED 15 September 1958



7C 55-0-4(C)

Figure 2-1. 7

THIS DOCUMENT  
ISSUED 15 September

A.




Figure 2-1. Typical Hydraulic Temperature and Pressure Indicating System

1. ANY INFORMATION AFFECTING THE NATIONAL DEFENSE OF THE UNITED STATES WITHIN THE MEANING OF THE ESPIONAGE LAWS, TITLE 18, U.S.C., SECTION 793, THE TRANSMISSION OR THE REVELATION OF ITS CONTENTS IN ANY MANNER TO AN UNAUTHORIZED PERSON IS PROHIBITED BY LAW

ISSUED 15 September 1958



~~CONFIDENTIAL~~

B.

UNCLASSIFIED



CONFIDENTIAL

ZE-7-137



7C 55 0-5 C

Figure 2-2. Panel Calibrating Twin Temperature Recorder



1 55 0 6 C

Figure 2-3. Panel Calibrating Twin Pressure Recorder

THIS DOCUMENT CONTAINS INFORMATION AFFECTING THE NATIONAL DEFENSE OF THE UNITED STATES WHICH IS UNCLASSIFIED BY THE NATIONAL ARCHIVES AND RECORDS ADMINISTRATION. THE INFORMATION IS BEING RELEASED TO THE PUBLIC IN ACCORDANCE WITH THE NATIONAL ARCHIVES AND RECORDS ADMINISTRATION'S POLICY ON THE RELEASE OF INFORMATION.

UNCLASSIFIED

CONFIDENTIAL

ISSUED 15 September 1958